

*See UM Consultant Procedures and Design Guidelines. All design guidelines posted are applicable. Information below supplements and supersedes information provided in Division 03 of those documents.*

### **General**

---

1. Interior floor expansion joints shall support heavy wheeled equipment and provide a smooth transition.
2. Install and seal cast in place sleeves at through floor penetrations. Top of sleeve at 1" AFF. Approved firestop system shall be incorporated and must result in a UL listed assembly. See Fire Stop section for more information.
3. The finish and slope of concrete surfaces shall match project scope and function (i.e., Slope to floor and shower drains, etc.).
4. When installing a mud slab for future use, provide troweled finish with sealer.

### **03 3006 Waterproofing Admixture for Cast-in-Place Admixture**

---

1. Specify a water-based polyvinyl acetate (PVA) bonding agent (such as Thoro Acryl 60, or equal) when bonding to existing concrete.

END OF SECTION